" SOFTEE " RECHARGING INSTRUCTIONS

1-REMOVE CLEAR BOWL OF PREFILTER (PUSH AND TURN CONNECTION)

2-FILL BOWL WITH CHARGING SALT SUPPLIED UNTIL FULL

3-REATTACH BOWL TO HEAD MAKING CERTAIN TO NOT DAMAGE ORING

4-TURN WATER SUPPLY ON TO ¼ TO ½ PRESSURE AND ALLOW WATER TO DISSOLVE SALT FROM HOUSING INTO THE "SOFTEE" (THIS SHOULD TAKE ABOUT 5 MINUTES)

5-TURN OFF WATER

6-NOW THAT ALL THE SALT HAS BEEN DISSOLVED, TAKE THE TIME TO REMOVE THE BOWL AGAIN AND INSTALL A NEW CARBON CARTRIDGE INTO THE HOUSING AND REATTACH BOWL TO HEAD OF FILTER.

7-ALLOW DISSOLVED SALT TO SIT IN "SOFTEE" FOR ABOUT 10-15 MINUTES ,THIS WILL ALLOW THE ION EXCHANGE TO TAKE PLACE.

8-TURN WATER ON AGAIN TO NORMAL PRESSURE AND FLUSH THE ENTIRE SYSTEM FOR 5-10 MINUTES.

9-THE "SOFTEE" IS NOW READY FOR USE AGAIN